

Reg. address	Content	Function code	Register length	Unit	Data type
4000	Serial number	03	2	-	HEX
4002	Meter code	03	1	-	HEX
4003	Meter ID (Mbus/Modbus)	03	1	-	Signed
4004	Baud Rate	03	1	-	Signed
4005	Protocol Version	03	2	-	Float ABCD
4007	Software Version	03	2	-	Float ABCD
4009	Hardware Version	03	2	-	Float ABCD
400B	Meter Amps	03	1	A	Signed
400C	CT rate	03	1	A	HEX
400D	S0 output rate	03	2	imp/s	Float ABCD
400F	Combined Code	03	1	-	Signed
4010	LCD cycle time	03	1	sec.	HEX
4011	Parity setting	03	1	-	Signed
4012	Current direction L1	03	1	-	ASCII
4013	Current direction L2	03	1	-	ASCII
4014	Current direction L3	03	1	-	ASCII
4015	Err-02*	03	1	-	Signed
4016	Power on off counter	03	1	-	Signed
4017	Present Quadrant	03	1	-	Signed
4018	Quadrant L1	03	1	-	Signed
4019	Quadrant L2	03	1	-	Signed
401A	Quadrant L3	03	1	-	Signed
401B	Checksum	03	2	-	HEX
401D	Active status word	03	2	-	HEX
401F	CT mode	03	1	A	Signed

Reg. address	Content	Function code	Register length	Unit	Data type
5000	Voltage*	03	2	V	Float ABCD
5002	L1 Voltage	03	2	V	Float ABCD
5004	L2 Voltage	03	2	V	Float ABCD
5006	L3 Voltage	03	2	V	Float ABCD
5008	Grid Frequency	03	2	Hz	Float ABCD
500A	Current*	03	2	A	Float ABCD
500C	L1 Current	03	2	A	Float ABCD
500E	L2 Current	03	2	A	Float ABCD
5010	L3 Current	03	2	A	Float ABCD
5012	Total Active Power	03	2	kW	Float ABCD
5014	L1 Active Power	03	2	kW	Float ABCD
5016	L2 Active Power	03	2	kW	Float ABCD
5018	L3 Active Power	03	2	kW	Float ABCD
501A	Total reactive power	03	2	kvar	Float ABCD
501C	L1 reactive power	03	2	kvar	Float ABCD
501E	L2 reactive power	03	2	kvar	Float ABCD
5020	L3 reactive power	03	2	kvar	Float ABCD
5022	Total Apparent Power	03	2	kVA	Float ABCD
5024	L1 Apparent Power	03	2	kVA	Float ABCD
5026	L2 Apparent Power	03	2	kVA	Float ABCD
5028	L3 Apparent Power	03	2	kVA	Float ABCD
502A	Power Factor	03	2	-	Float ABCD
502C	L1 Power Factor	03	2	-	Float ABCD
502E	L2 Power Factor	03	2	-	Float ABCD
5030	L3 Power Factor	03	2	-	Float ABCD

Reg. address	Content	Function code	Register length	Unit	Data type
6000	Total Active Energy	03	2	kWh	Float ABCD
6002	T1 Total Active Energy	03	2	kWh	Float ABCD
6004	T2 Total Active Energy	03	2	kWh	Float ABCD
6006	L1 Total Active Energy	03	2	kWh	Float ABCD

6008	L2 Total Active Energy	03	2	kWh	Float ABCD
600A	L3 Total Active Energy	03	2	kWh	Float ABCD
600C	Forward Active Energy	03	2	kWh	Float ABCD
600E	T1 Forward Active Energy	03	2	kWh	Float ABCD
6010	T2 Forward Active Energy	03	2	kWh	Float ABCD
6012	L1 Forward Active Energy	03	2	kWh	Float ABCD
6014	L2 Forward Active Energy	03	2	kWh	Float ABCD
6016	L3 Forward Active Energy	03	2	kWh	Float ABCD
6018	Reverse Active Energy	03	2	kWh	Float ABCD
601A	T1 Reverse Active Energy	03	2	kWh	Float ABCD
601C	T2 Reverse Active Energy	03	2	kWh	Float ABCD
601E	L1 Reverse Active Energy	03	2	kWh	Float ABCD
6020	L2 Reverse Active Energy	03	2	kWh	Float ABCD
6022	L3 Reverse Active Energy	03	2	kWh	Float ABCD
6024	Total Reactive Energy	03	2	kvarh	Float ABCD
6026	T1 Total Reactive Energy	03	2	kvarh	Float ABCD
6028	T2 Total Reactive Energy	03	2	kvarh	Float ABCD
602A	L1 Total Reactive Energy	03	2	kvarh	Float ABCD
602C	L2 Total Reactive Energy	03	2	kvarh	Float ABCD
602E	L3 Total Reactive Energy	03	2	kvarh	Float ABCD
6030	Forward Reactive Energy	03	2	kvarh	Float ABCD
6032	T1 Forward Reactive Energy	03	2	kvarh	Float ABCD
6034	T2 Forward Reactive Energy	03	2	kvarh	Float ABCD
6036	L1 Forward Reactive Energy	03	2	kvarh	Float ABCD
6038	L2 Forward Reactive Energy	03	2	kvarh	Float ABCD
603A	L3 Forward Reactive Energy	03	2	kvarh	Float ABCD
603C	Reverse Reactive Energy	03	2	kvarh	Float ABCD
603E	T1 Reverse Reactive Energy	03	2	kvarh	Float ABCD
6040	T2 Reverse Reactive Energy	03	2	kvarh	Float ABCD
6042	L1 Reverse Reactive Energy	03	2	kvarh	Float ABCD
6044	L2 Reverse Reactive Energy	03	2	kvarh	Float ABCD
6046	L3 Reverse Reactive Energy	03	2	kvarh	Float ABCD
6048	Tariff	03	1	-	Signed
6049	Resettable day counter	03	2	kWh	Float ABCD

### Write

Reg. address	Content	Function code	Register length	Unit	Data type
4003	Modbus ID	06	1	-	Signed
Command:	01 06 4003 000A (new ID: 10)		01~247 - 01 default - 00 broadcast		
4004	Baud Rate	06	1	-	Signed
Command:	01 06 4004 25 80 (new Baudrate: 9600)		300 - 600 - 1200 - 4800 - 9600		
400D	S0 output rate	10	2	imp/s	Float ABCD
Command:	01 10 400D 0002 04 41 20 00 00 (new S0: 10)		10.000 - 2.000 - 1.000 - 100 - 10 - 1 - 0,1 - 0,01		
400F	Combined Code	06	1	-	Signed
Command:	01 06 400F 000A (new code: 10 F-R)		01, 04, 05, 06, 09, 10, 11		
4010	LCD cycle time	06	1	sec.	HEX
Command:	01 06 4010 0025 (new time: 25 sec.)		01~30		
4011	Parity setting	06	1	-	Signed
Command:	01 06 4011 0002 (new parity: none)		01: even - 02: none - 03: odd		
4016	Power down counter	06	1	-	Signed
Command:	01 06 4016 0000		Reset to 0		
6048	Tariff	06	1	-	Signed
Command:	01 06 6048 0002 (new tariff: 2)		01: T1 - 02: T2		
6049	Resettable day counter	10	1	kWh	Float ABCD
Command:	01 10 6049 0002 04 0000 0000		Reset to 0		

\*PRO1 only